



# Kirby Morgan Dive Systems, Inc.®

1430 Jason Way Santa Maria, California 93455

Phone: 805/928-7772 Fax: 805/928-0342

www.KirbyMorgan.com email: kmdsi@KirbyMorgan.com

## Part #525-720 Stainless Steel Chin Strap Assembly Kit

PART #	DESCRIPTION	QTY
505-748	Stainless Steel Chin Strap Assembly w/ Snaps	1
530-037	Screw	2



### NOTE

The adjustment strap should pull toward the right side of the helmet when it is on your head.



1. Apply Loctite® 248 to the screws that secure the chin strap.

2. Install the two screws that hold the chin strap in position, using the two screws supplied with the chin strap replacement kit.



3. Tighten the screws with a torque screwdriver in accordance with the torque specification found in the correct table (correct model) of the manual. See "Torque Specs" module.

