



1430 Jason Way Santa Maria, California 93455 Phone: 805/928-7772 Fax: 805/928-0342

www.KirbyMorgan.com email: kmdsi@KirbyMorgan.com

## Part # 525-116 Front Standoff Kit

Part #	Description	Qty
530-059	Screw	2
540-039	Front Standoff	2

- 1. Apply medium thread locking compound Loctite® 248 to screw P/N 530-059.
- 2. Attach P/N 540-039 front standoff with screw P/N 530-059 onto helmet shell or bottom ring and torque to 15 inch pounds.





## **A** CAUTION

Use only KMDSI original replacement parts. The use of other manufacturers' parts will interfere with the performance characteristics of your life support equipment and may jeopardize your safety. Additionally, any substitutions will void any warranties offered by KMDSI. When ordering spares, always insist on Kirby Morgan Genuine Parts.

