



Kirby Morgan Dive Systems, Inc.®

1430 Jason Way Santa Maria, California 93455

Phone: 805/928-7772 Fax: 805/928-0342

www.KirbyMorgan.com email: kmddsi@KirbyMorgan.com

Part #525-745 Head Cushion Foam Spacer (HCFS) Kit

Parts Needed:

Part #	Description	Qty
510-837	Head Cushion Foam Spacer Assembly	1

Installation:

Note: In September of 2012 the head cushion foam spacer (HCFS) was upgraded with an elastic/Velcro strap at the top front part of the HCFS bag. This new feature is intended to be used with head cushions P/N 510-754, or 510-521 soon to have the mating Velcro patches.

Note: If using the HCFS with P/N 510-682 or a P/N 510-521 without a Velcro patch, the elastic/Velcro strap can simply be folded over the top front portion between the head cushion and the helmet shell, or it may be trimmed off if desired.

1. Install the HCFS into the top inside portion of the head cushion. Wrap the elastic/Velcro strap around the front top edge and attach onto the mating Velcro patch in front of the hanging loop.

⚠ CAUTION

Use only KMDSI original replacement parts. The use of other manufacturers' parts will interfere with the performance characteristics of your life support equipment and may jeopardize your safety. Additionally, any substitutions will void any warranties offered by KMDSI. When ordering spares, always insist on Kirby Morgan Genuine Parts.



The tag on the HCFS and sewing seam should be facing the back against the head cushion

Align the front of the HCFS with the front edge of the head cushion, wrap the elastic/Velcro Strap around to the top of the head cushion and secure.

Kirby Morgan Dive Systems, Inc.®

1430 Jason Way Santa Maria, California 93455

Phone: 805/928-7772 Fax: 805/928-0342

www.KirbyMorgan.com email: kmdsi@KirbyMorgan.com



Donning:



Hold the HCFS towards the back of the helmet when donning.



⚠ CAUTION

Ensure that the HCFS is properly positioned against the back of the head/neck and does not get caught between the helmet ring and the neck dam rings when closing the helmet. Failure to do so could result in an improper seal.

Care & Maintenance:

Daily: Post dive rinse with fresh water, air dry.

Periodic: Remove foam and fresh water rinse. Hand wash the HCFS bag using a mild soap, rinse with fresh water and air dry.

Stuffing:

1. Stuff the neck foam block and top foam into the HCFS bag. Close the Velcro.

Note: Match the shape of the neck foam block with the shape of the HCFS bag.

Match the shape of the foam block with the shape of the pocket

