



Kirby Morgan Dive Systems, Inc.®

1430 Jason Way Santa Maria, California 93455

Phone: 805/928-7772 Fax: 805/928-0342

www.KirbyMorgan.com email: kmdsi@KirbyMorgan.com

Part #525-363 SL 17C, 17K and KM 37 Soft Goods Overhaul Kit with SuperFlow® 350 Regulator

| PART # | DESCRIPTION | QTY | PART # | DESCRIPTION | QTY |
|---------|-------------------|-----|---------|--------------------------------|-----|
| 310-003 | O-ring | 1 | 510-561 | Valve, Water Dump, Black | 1 |
| 510-007 | O-ring | 4 | 510-580 | Seat, Inlet Valve | 1 |
| 510-008 | O-ring | 2 | 510-776 | Exhaust Valve | 2 |
| 510-010 | O-ring | 3 | 520-024 | Packing | 1 |
| 510-011 | O-ring | 2 | 520-030 | Washer | 1 |
| 510-012 | O-ring | 1 | 520-031 | Washer | 1 |
| 510-014 | O-ring | 1 | 520-032 | Washer | 1 |
| 510-015 | O-ring | 1 | 520-033 | O-ring, Teflon® | 1 |
| 510-029 | O-ring | 1 | 520-042 | 11" Tie-Wrap | 4 |
| 510-033 | O-ring | 2 | 520-167 | Teflon® Washer for Swing Catch | 1 |
| 510-260 | O-ring, View Port | 1 | 525-032 | Kit, Whisker Clamp Replacement | 1 |
| 510-401 | Gasket | 1 | 525-330 | Kit, One-Way Valve | 1 |
| 510-450 | O-ring, Neck Ring | 1 | 530-028 | Nut | 1 |
| 510-481 | O-ring | 1 | 530-303 | Lock Nut | 1 |
| 510-483 | O-ring | 1 | 530-601 | Retaining Pin | 1 |
| 510-490 | O-ring | 2 | 540-095 | Packing Washer | 1 |
| 510-550 | Valve, Oral Nasal | 1 | | | |
| 510-552 | Exhaust Valve | 1 | | | |
| 510-553 | Diaphragm | 1 | | | |

***See next page for O-ring Identification**

O-rings should be lightly lubricated with food grade silicone Dow Corning® 111 or equivalent in accordance with the operations and maintenance manual. Christo-Lube® may also be used. At a minimum, all helmet or BandMask® O-rings should be replaced at least once a year in accordance with the A2.1 checklist for the helmet or mask being inspected. During daily and monthly maintenance, O-rings and valves may be reused providing no damage or deformation is found. O-rings and valves may require replacement more often than yearly if the helmet or mask use is extreme, or if the helmet or mask is used in waters containing oil or chemical contamination. Daily cleaning and inspections as well as performing the monthly inspection (A2.2 checklist) will identify the need more accurately than simply placing a number of hours between overhaul. Store spare O-rings, valves and soft goods in a cool, dark, dry place. Avoid prolonged exposure to temperatures above 90 degrees Fahrenheit and/or exposure to ultra violet rays. Do not lubricate exhaust valves. Lubricating valves can cause dirt to stick, allowing leakage.



Kirby Morgan Dive Systems, Inc.®

1430 Jason Way Santa Maria, California 93455

Phone: 805/928-7772 Fax: 805/928-0342

www.KirbyMorgan.com email: kmdsi@KirbyMorgan.com



310-003

1. Low Pressure Side Block Port Plug (*Bottom*) (Qty. 1)



510-015

1. Bonnet Nut for Steady Flow (Qty. 1)



510-483

1. One Way Valve Mounting O-ring (Qty. 1)



510-007

1. Water Dump Adapter Cover (Qty. 2)



510-008

1. Nose Block Shaft (Qty. 2)



510-029

1. Comm Port (Qty. 2)



510-490

1. Regulator Mount Nut (Qty. 1)




510-010

1. Nose Block Guide Seal (Qty. 1)
2. Steady Flow (Qty. 1)



510-011

1. Regulator Adjustment Knob (Qty. 1)



510-033

1. Quad Exhaust Cover (Qty. 1)



520-033

1. Bent Tube (Qty. 1)



510-012

1. Bent Tube (Qty. 1)



510-014

1. Regulator Inlet Nipple (Qty. 1)



510-481

1. Comm Packing Gland (Qty. 1)

NOT SHOWN

510-260 6.5" × 0.153"

1. Face Port O-ring

510-450 9" × 0.278"

1. Neck Ring O-ring

