

**KMB 18/28 (BANDMASK)
MONTHLY MASK INSPECTION
APPENDIX A2.2
08-01-17**

This inspection is the minimum recommended maintenance and **should be** performed at least **ONCE A MONTH** with Mask(s) in continuous use (used for more than 20 diving days in a month) or at least every **TWO (2) MONTHS**, with Mask(s) used less than 10 diving days a month.

This checklist is intended to aid persons performing routine maintenance and inspections of the KMB 18/28 Band Masks. This checklist should be used in conjunction with the Modular Operations and Maintenance Manual for the Band Mask model being serviced, and is primarily intended to be used as a guide and to document the maintenance as it is completed. Specific detailed procedures for each section of this checklist can be found in the Modular Operations and Maintenance Manuals. This checklist when completed should be retained in the equipment maintenance files. This checklist is generic in nature and is intended to be used for all models of KMDSI Band Masks.

NOTE: Mask(s) being used in extreme environments will require more frequent inspection.

NOTE: During removal of components for inspection, O-rings and other consumable items may be reused, providing they are clean and a visual inspection does not reveal any damage or deterioration.

NOTE: Perform the Side Block/Demand Regulator inspection procedures with gas supplies not connected to the Side Block. Attach the gas supply at Step 5 of the “Side Block/Demand Regulator” inspection procedure.

Date:
Mask Serial #:
Associated Equipment Serial #(s):
Technician (print name):

Kirby Morgan, SuperLite, Band Mask, KMB Band Mask, EXO, SuperMask, SuperFlow, and Rex are all registered trademarks of Kirby Morgan Dive Systems, Inc. Use of these terms to describe products that are not manufactured by KMDSI is not permitted without written permission from KMDSI.

© Copyright 1970-2017 Kirby Morgan Dive Systems, Inc. All rights reserved. KMDSI manuals, checklists and technical and training information is made available for the express use of owner/user of this Kirby Morgan products. No part of this material may be reproduced, stored in any retrieval system, or transmitted, or used in any form or by any means, whether graphic, electronic, mechanical, photocopy, or otherwise by technology known or unknown, without the prior written permission of Kirby Morgan Dive Systems, Inc

Copyright 2003-2017 Dive Lab®, Inc. All rights reserved. TechTrnG 03101

PROCEDURES	INITIALS
HOOD ASSEMBLY	
1. Remove Head Harness (Spider) and inspect for signs of tearing, deterioration, and/or damage. Ensure all five legs of the Head Harness are present. Guidance Modular O & M Manual.	
2. Remove the Earphones from their pockets in the Hood. Remove the Hood from the Mask. Perform a visual inspection of all components. Guidance Modular O & M Manual.	
3. Visually inspect the Hood for signs of damage and/or deterioration. Guidance Modular O & M Manual.	
4. Visually inspect all metal parts of the Band Assembly, Band Keeper, components, including the Band Screws, for damage. Replace if necessary. Guidance Modular O & M Manual.	
MASK ASSEMBLY	
1. Visually inspect the Mask exterior for loose and/or missing fasteners and obvious signs of fiberglass (KMB18) or thermoplastic (KMB28) damage; including cracks, gouges or depressions.	
NOTE: On the KMB 18, any gouges in the fiberglass shell deeper than 1/16” (1.59mm) that expose fiberglass should be repaired. Fiberglass and gel coat repairs MUST be completed by a technician that has received certification for Helmet Shell repairs by KMDSI or Dive Lab, Inc. Any cracks or depressions with fractures must be checked by an Authorized KMDSI Repair Facility.	
2. Remove the Covers and Protectors from the Earphones. Remove Microphone from Oral Nasal Mask. Inspect and repair or replace as necessary. Perform a complete communications check. Guidance Modular O & M Manual.	
CAUTION: The Nose Block device MUST be removed when installing or removing the Oral Nasal Mask. Stretching the Oral Nasal Mask over the Nose Block Device can cause the Oral Nasal Mask to tear.	

Kirby Morgan, SuperLite, Band Mask, KMB Band Mask, EXO, SuperMask, SuperFlow, and Rex are all registered trademarks of Kirby Morgan Dive Systems, Inc. Use of these terms to describe products that are not manufactured by KMDSI is not permitted without written permission from KMDSI.

© Copyright 1970-2017 Kirby Morgan Dive Systems, Inc. All rights reserved. KMDSI manuals, checklists and technical and training information is made available for the express use of owner/user of this Kirby Morgan products. No part of this material may be reproduced, stored in any retrieval system, or transmitted, or used in any form or by any means, whether graphic, electronic, mechanical, photocopy, or otherwise by technology known or unknown, without the prior written permission of Kirby Morgan Dive Systems, Inc

Copyright 2003-2017 Dive Lab®, Inc. All rights reserved. TechTrnG 03101

3. Remove the Nose Clearing Device. Clean and inspect the Nose Clearing Pad, Shaft and O-Rings. If O-Rings show signs of damage replace. Guidance Modular O & M Manual.	
4. Remove the Oral Nasal Mask and Oral Nasal Valve as an assembly. Clean and inspect Mask and Valve Assembly for damage. Replace the Oral Nasal Mask if any damage is found. Replace the Valve if it appears dried, stiff, and/or does not lay flat or if parts show sign of damage. Reinstall Valve Assembly into Oral Nasal Mask. Guidance Modular O & M Manual.	
5. Clean and inspect the Nose Clearing Pad, Shaft and O-rings for wear. Replace the Pad if deteriorated or damaged. Replace O-rings if worn. Lightly lubricate O-rings and Shaft then reinstall. Guidance Modular O & M Manual.	
6. Reinstall Oral Nasal Mask with Valve Assembly back onto Regulator Mount Nut. Guidance Modular O & M Manual.	
7. Remove the Comfort Insert [KMB 18 only]. Clean and inspect the Comfort Insert and its fasteners for damage and/or deterioration. Mark N/A for KMB 28. Reinstall. Guidance Modular O & M Manual.	
8. Without air to the Side Block, check the operation of the Defogger/Steady Flow Valve and EGS Valve. If the Valves do not operate smoothly, they must be overhauled or replaced. Guidance Modular O & M Manual.	
9. Remove the Cover, Water Dump. Inspect the Main Exhaust/Dewatering Valve and Seat for damage and/or contamination. Ensure the Valve material is not hardened, distorted, and/or warped. Replace the Valve if questionable. Reinstall the Cover.	
SIDE BLOCK/DEMAND REGULATOR	
1. Check the Umbilical Supply One Way Valve for proper operation by sucking on the Umbilical Adapter with the Emergency Valve open. No gas should be drawn thru the One Way Valve.	
2. Remove the Regulator Cover Clamp, Cover, and Diaphragm. Visually inspect the interior of the Regulator Body for corrosion and/or contamination. Clean as necessary. Guidance Modular O & M Manual.	
3. Carefully inspect the Diaphragm for cuts, tears, and deterioration. If any damage is found, replace the Diaphragm.	

Kirby Morgan, SuperLite, Band Mask, KMB Band Mask, EXO, SuperMask, SuperFlow, and Rex are all registered trademarks of Kirby Morgan Dive Systems, Inc. Use of these terms to describe products that are not manufactured by KMDSI is not permitted without written permission from KMDSI.

© Copyright 1970-2017 Kirby Morgan Dive Systems, Inc. All rights reserved. KMDSI manuals, checklists and technical and training information is made available for the express use of owner/user of this Kirby Morgan products. No part of this material may be reproduced, stored in any retrieval system, or transmitted, or used in any form or by any means, whether graphic, electronic, mechanical, photocopy, or otherwise by technology known or unknown, without the prior written permission of Kirby Morgan Dive Systems, Inc

Copyright 2003-2017 Dive Lab®, Inc. All rights reserved. TechTrnG 03101

<p>4. Carefully check the Regulator Exhaust Valve for warping, distortion, stiffness, and/or damage. This is checked by pressing on the Flapper Valve from inside the Regulator. Check the Regulator Body Valve Seat Spokes. The Spokes should be flat and even. Straighten if deformed. If the Valve shows signs of damage and/or deterioration, replace the Valve. Guidance Modular O & M Manual.</p>	
<p>5. Reinstall the Diaphragm and Cover. Attach an air supply source to the Umbilical Adapter and set the supply pressure to between 135 - 150 psig (9.3 – 10.3 bar). Rotate regulator Adjustment Knob out, until a slight free flow develops, then turn in until the free flow just stops. Guidance Modular O & M Manual.</p>	
<p>6. Depress the Purge Button. On the SuperFlow and SuperFlow 350 demand regulators the button should travel 1/16”-1/8” (6 -12mm) before gas starts to flow and a strong purge should be felt when the button is fully depressed. If the regulator purge travel is less than 1/16” (6mm) or greater than 1/8” (12mm), readjust the lever, Guidance Modular O & M Manual. For the 450 and 455 balanced regulators, when the cover is depressed approximately 1/4” (6.35mm) gas should start to flow and when pushed beyond 1/4”-1/2” (6 -12 mm) a strong flow of gas should be present. Guidance Modular O & M Manual.</p>	
<p>7. Check the Steady Flow Valve for proper operation.</p>	
<p>NOTE: The Defogger/Steady Flow Valve will rotate approximately two complete revolutions from closed to full open. With the air pressure to the Mask between 135 - 150 psig (9.3 - 10.3 bar), turning the Defogger/Steady Flow Valve one full rotation should result in a strong flow of gas through the Defogger Train.</p>	
<p>8. Secure the gas supply, then bleed down and remove the gas supply from the Umbilical Adapter.</p>	
<p>9. Attach a regulated gas supply (normally the EGS system), adjusted to between 135 – 150 psig (9.3 – 10.3 bar), to the Emergency Valve on the Side Block. On the Side Block, open the Emergency Supply Valve all the way, and then slowly open the regulated gas supply. Check the function of the Regulator Purge, regulator Adjustment Knob, and the Defogger/Steady Flow Valve in accordance with previous steps 6 and 7. Check for gas exiting from the One Way Valve. There should be no gas exiting the Umbilical Adapter.</p>	

Kirby Morgan, SuperLite, Band Mask, KMB Band Mask, EXO, SuperMask, SuperFlow, and Rex are all registered trademarks of Kirby Morgan Dive Systems, Inc. Use of these terms to describe products that are not manufactured by KMDSI is not permitted without written permission from KMDSI.

© Copyright 1970-2017 Kirby Morgan Dive Systems, Inc. All rights reserved. KMDSI manuals, checklists and technical and training information is made available for the express use of owner/user of this Kirby Morgan products. No part of this material may be reproduced, stored in any retrieval system, or transmitted, or used in any form or by any means, whether graphic, electronic, mechanical, photocopy, or otherwise by technology known or unknown, without the prior written permission of Kirby Morgan Dive Systems, Inc

Copyright 2003-2017 Dive Lab®, Inc. All rights reserved. TechTrnG 03101

EMERGENCY GAS SUPPLY (EGS)	
NOTE: The Emergency Gas System consists of a good quality First Stage Regulator equipped with a submersible pressure gauge, an Over Pressure Bleed/Relief Valve, and an Emergency Gas Supply Hose that connects to the Emergency Valve on the Mask Side Block.	
1. Check the hydrostatic date and last visual inspection record (“VIP”) of the cylinder. Ensure date(s) are within the specified range. The VIP is done at least annually and the hydrostatic test is done at least every five years.	
2. Check the maintenance record of the EGS components to ensure the First Stage Regulator’s maintenance has been performed in accordance with the manufacturer’s recommendations.	
3. Check all Hoses for signs of blisters, cover slippage, cuts, and/or abrasions. Replace any Hose(s) that show signs of leakage/damage. If a Quick Connect EGS hose is being used, inspect quick connect and fittings for signs of wear/damage.	
4. If a submersible pressure gauge is used, ensure it has been compared to a gauge of known accuracy. Inspect the hose and fittings for signs of damage and deterioration. Replace end fitting O-rings.	
5. Test the First Stage Bleed/Relief Valve. Guidance, Appendix 4: Bleed/Relief Valve Cleaning, Inspection, and Overhaul Procedures”.	
6. Log the lifting pressure _____ psig.	
NOTE: An adjustable First Stage Regulator and a Gas Cylinder with a minimum of 500 psig (34.5 bar) available are required for this step.	
NOTE: The Bleed/Relief Valve should be adjusted to start relieve between 180 - 200 psig (12.4 – 13.8 bar) when tested.	
7. Check the over-bottom setting of the First Stage Regulator to ensure it is within the manufacturer’s specified pressure range. For KMDSI Helmets and Masks, the minimum over-bottom for the emergency supply is 135 psig (9.3 bar) and the maximum 165 psig (11.4 bar). Log the intermediate pressure.	
8. Perform a leak check of all EGS components and fittings using soapy water in a pressurized condition. Repair/replace items as necessary.	
9. Inspect the Harness Assembly for signs of wear and/or damage. Repair/replace as necessary.	

Kirby Morgan, SuperLite, Band Mask, KMB Band Mask, EXO, SuperMask, SuperFlow, and Rex are all registered trademarks of Kirby Morgan Dive Systems, Inc. Use of these terms to describe products that are not manufactured by KMDSI is not permitted without written permission from KMDSI.

© Copyright 1970-2017 Kirby Morgan Dive Systems, Inc. All rights reserved. KMDSI manuals, checklists and technical and training information is made available for the express use of owner/user of this Kirby Morgan products. No part of this material may be reproduced, stored in any retrieval system, or transmitted, or used in any form or by any means, whether graphic, electronic, mechanical, photocopy, or otherwise by technology known or unknown, without the prior written permission of Kirby Morgan Dive Systems, Inc

Copyright 2003-2017 Dive Lab®, Inc. All rights reserved. TechTrnG 03101

Recorded service in helmet maintenance log book YES _____ NO _____

NOTE: KMDSI strongly recommends that only trained certified KMDSI technicians perform overhauls. The below statement is intended to discourage non trained and non certified persons from posing as certified KMDSI technicians.

I _____ hereby certify that I have performed the work required in the A2.1 and that I am a certified KMDSI / Dive Lab technician.

Print name _____ Signature _____

Date _____ ID# _____ Expiration date _____

I _____ hereby certify that I have performed the work required in the A2.1 and I am not a certified KMDSI / Dive Lab technician

Technician / Owner: Print name _____

Comments: _____

KMDSI **highly** recommends that a certified KMDSI Repair Technician make all repairs and that only genuine KMDSI repair and replacement parts be used. Owners of KMDSI products that elect to do their own repairs and inspections should only do so if they possess the knowledge and experience. All inspections, maintenance, and repairs should be completed using the appropriate KMDSI Modular Operations and Maintenance Manual(s). Persons performing repairs should retain all replacement component receipts for additional proof of maintenance history. Should any questions on procedures, components, or repairs arise, please contact Kirby Morgan Dive Systems, Inc., by telephone at (805) 928-7772 or via e-mail at kmdsi@kirbymorgan.com, or contact Dive Lab, Inc., by telephone at (850) 235-2715 or via e-mail at divelab@divelab.com.

NOTE: Use your Maintenance and repair log book P/N 125-001, to record all the maintenance performed.

Kirby Morgan, SuperLite, Band Mask, KMB Band Mask, EXO, SuperMask, SuperFlow, and Rex are all registered trademarks of Kirby Morgan Dive Systems, Inc. Use of these terms to describe products that are not manufactured by KMDSI is not permitted without written permission from KMDSI.

© Copyright 1970-2017 Kirby Morgan Dive Systems, Inc. All rights reserved. KMDSI manuals, checklists and technical and training information is made available for the express use of owner/user of this Kirby Morgan products. No part of this material may be reproduced, stored in any retrieval system, or transmitted, or used in any form or by any means, whether graphic, electronic, mechanical, photocopy, or otherwise by technology known or unknown, without the prior written permission of Kirby Morgan Dive Systems, Inc

Copyright 2003-2017 Dive Lab®, Inc. All rights reserved. TechTrnG 03101