



# Kirby Morgan Dive Systems, Inc.®

1430 Jason Way Santa Maria, California 93455

Phone: 805/928-7772 Fax: 805/928-0342

www.KirbyMorgan.com email: kmdsi@KirbyMorgan.com

## M-48 Post-Dive Cleaning and Inspection

**Diver Name:** \_\_\_\_\_ **Date:** \_\_\_\_\_

No.	Step	Init.
1.	Remove pod from mask.	
2.	Soapy Solution Wash: Prepare solution of warm water (80-100°F) and mild hand type dishwashing soap. Agitate components in solution for 2-3 minutes; use soft bristle brush or cleaning rag. Allow mask to soak for 10 minutes then rinse thoroughly with clean fresh water.	
3.	Ensure all debris such as sand and dirt is removed from regulator mouthpiece and BOV/DSV inhalation and exhalation ports. Clean the regulator; BOV or DSV IAW manufacturer's instructions. Thoroughly rinse the tilt-to-purge valve (17).	
4.	Rotate Regulator Adjustment Knob (26) fully out (counter clockwise), if equipped.	
5.	Gently blow dry mask and pod with clean, oil-free low pressure air (less than 30 psig, or 1.8 bar) or hang and let air dry completely. Allow mask to dry completely before storage. Avoid direct sunlight. To avoid spotting, dry view ports with a clean, lint free cloth.	
6.	<u>Inspect mask for damaged, worn, or missing parts.</u>	
7.	Dry and store mask and pod out of sunlight and fluorescent light, preferably in protective bag or pouch.	

